


User's Guide


micro-line[®] Busmaster BSP

For the C6713Compact-2

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	<p>Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 2</p>
---	--	---

Contents

1	PREFACE.....	5
1.1	Document Organization.....	5
1.2	Documentation Overview	5
1.3	Notational Conventions	5
1.4	Trademarks	6
1.5	Revision History	7
2	INTRODUCTION	8
3	FUNCTIONAL OVERVIEW	9
3.1	micro-line® Peripheral Interface	9
3.2	Host Port Interface (HPI).....	11
3.3	IEEE1394 Data Streaming.....	13
4	ADDRESS MAP	15
4.1	C6713Compact-2 Address Map.....	15
4.2	Address Map of the micro-line® Busmaster BSP	15
4.2.1	Bus Width Configuration.....	15
5	REGISTER DESCRIPTION	18
5.1	IEEE1394 Streaming Registers	18
5.2	FPGA Registers	18
5.2.1	Chip Select Control Register	18
5.2.2	FPGA Version Register	19
5.2.3	LED Control Register	19
5.2.4	Clock Control Register	19
5.2.5	Interrupt Control Register	20
6	SETTING UP EMIF TIMINGS	21
7	SIGNALS ON THE MICRO-LINE CONNECTOR	22
8	INDIVIDUAL SIGNAL DESCRIPTION.....	23
8.1	micro-line Peripheral Interface.....	23
8.1.1	Connector A	23

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	<p>Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 3</p>
---	--	---


8.1.2	Connector B	23
8.1.3	Connector D	23
8.1.4	Connector E	24
8.2	Host Port Interface	25
8.2.1	Connector BB	25
8.3	Other Signals	26
9	SIGNAL LEVELS	27
10	SIGNAL TIMINGS	28
10.1	micro-line Peripheral Interface.....	28
10.2	Host Port Interface	28
11	CONNECTION EXAMPLES	29
11.1	Peripheral Interface.....	29
11.2	Host Port Interface	29
11.2.1	Host Port Connection with Common Strobe and Direction Select.....	30
11.2.2	Host Port Connections with Separate Strobe Signals	30
11.2.3	Host Port Connections with Separate Strobe Signals Alternative Method	31
12	APPLICATION EXAMPLES	32
12.1	Default FFS Application (toggle_led).....	32
12.1.1	Loading and Accessing the FPGA (toggle_led_fpga)	32
12.1.2	Micro-line® Peripheral Interface.....	32
12.1.3	General IEEE1394 Operation (asynctst)	33
12.1.4	Software Streaming (isotst)	35
13	LIST OF ABBREVIATIONS AND ACRONYMS USED IN THIS DOCUMENT	38
14	LITERATURE REFERENCES	40

List of Tables

Table 1: HPI signals	12
Table 2: Valid HPI access combinations	13
Table 3: HPI registers.....	13
Table 4: C6713Compact-2 address map	15
Table 5: Default address map of this BSP	15
Table 6: Modified address map with CE2 configured for 16 bit.....	16
Table 7: Modified address map with CE2 configured for 8bit.....	16
Table 8: Modified address map with CE3 configured for 32 bit.....	16
Table 9: Modified address map with CE3 configured for 8 bit.....	17
Table 10: FPGA register locations	18
Table 11: FPGA register bit summary in default EMIF configuration	18
Table 12: Possible EMIF_CLK settings.....	20
Table 13: Timings for the CE2 and CE3 address spaces	21
Table 14: Pinout of micro-line® connectors A through E	22
Table 15: Pinout of micro-line® connector X.....	22
Table 16: Recommended operating conditions.....	27
Table 17: Peripheral interface timings.....	28
Table 18: HPI Timings (FPGA part only).....	28
Table 19: HPI register address map.....	30
Table 20: HPI register address map using address bit for direction select	31

List of Figures

Figure 1: Block diagram of the busmaster BSP	9
Figure 2: micro-line® peripheral interface	10
Figure 3: HPI block diagram.....	11
Figure 4: Available HPI signals	12
Figure 5: IEEE1394 data streaming block diagram.....	14
Figure 6: Peripheral interface connection example	29
Figure 7: Host port connections when using a single strobe.....	30
Figure 8: Host port connections when using separate strobe signals	30
Figure 9: Host port connections when using address bit for direction selection.....	31
Figure 10: Startup message of toggle_led_fpga	32
Figure 11: Sample <i>asynctst</i> session.....	35
Figure 12: Sample <i>isotst</i> session	36
Figure 13: Recorded <i>isotst</i> data	37

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	<p>Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 5</p>
---	--	---

1 Preface

1.1 Document Organization

This document is organized as follows:

- Chapter 1 gives some general information such as notational conventions and documentation overview.
- Chapter 2 introduces the micro-line busmaster[®] BSP
- Chapter 3 gives an overview of the components that make up the BSP
- Chapter 4 lists the address ranges implemented by the FPGA
- Chapter 5 describes the FPGA registers
- Chapter 6 explains the required EMIF settings
- Chapter 7 gives an overview of the signals available at the micro-line[®] connector
- Chapter 8 describes each signal in detail
- Chapter 9 lists the electrical characteristics of the available signals
- Chapter 10 lists signal timings
- Chapter 11 gives examples for connecting hardware to the C6713Compact-2
- Chapter 12 describes the application examples available with this BSP
- Chapter 13 lists abbreviations and acronyms used in this document
- Chapter 14 lists further documentation

1.2 Documentation Overview

This chapter lists the documentation from Orsys that is shipped together with software development kits that contain the micro-line[®] busmaster BSP. Further documents from other vendors are listed in chapter and are referenced throughout the document in square brackets.

C6713Compact-2 Hardware Reference Guide [1] ([C6713Cpt-2_hrg.pdf](#)):

Describes the basic hardware (without any FPGA functionality) of the C6713Compact-2.

Flash File System User's Guide [2] ([ffs_ug.pdf](#)):

Documents the Flash File System Utilities. Use this document for information on how to store files in Flash memory.

Board Library User's Guide [3] ([boardlib.pdf](#)):

Describes the board library for the C6713Compact-2. Use this document for information on basic software development.

C6713Compact-2 DM Port Streaming Core User's Guide [4] ([C6713Cpt-2_str_core_ug](#)):

Describes the FPGA function block for IEEE1394 software streaming.

IEEE1394 embedded API User's Guide [5] ([embedded_API_ug](#)):

Describes the software interface to IEEE1394.

1.3 Notational Conventions

Names of registers, bit fields and single bits are written in capital letters.

Example: LLC_VERSION

Names of signals are also given in capital letters, active low signals are marked with a '/' at the beginning of the name.

Example: /RESETIN

Configuration parameters, function names, path names and file names are written in *italic* typeface.
 Example: *dev_id*

Source code, command line examples and text to be entered are given in a small, fixed-width typeface.

Example: `int a = 10;`

Menus and commands from menus and submenus are enclosed in double-quotes. Example:
 Create a new project using the "Create Project..." command from the "File" menu.

Keys to type on the keyboard are shown with a surrounding frame, e.g. F10. If a sequence of keys is to be typed, the keys are separated by commas: F10, ↵. If two keys must be pressed simultaneously, the key combination is shown with a plus sign: Alt + F.

The members of a bit field or a group of signals are numbered starting at zero, which is the least significant bit.

Example: CFG[4:0] identifies a group of five signals, where CFG0 is the least significant bit and CFG4 is the most significant bit.

If necessary, numbers are represented with a suffix that specifies their base.

Example: 12AB₁₆ is a hexadecimal number (base 16 = hexadecimal) and is equal to 4779₁₀.

The bit fields of a register are displayed with the most significant bit to the left. Below each bit field is a description of its read / write accessibility and its default value:

bit number		bit name													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
A	B	C	D	E	F	G			H	I	J	K	L	N	O
r,w,0	r,w,0	r,w,0	r,w,0	r,w,0	r,w,0	r,w,010 ₂			r,0	r,wc,0	w	r,w,0	rc,0	r,w,0	r,w,0
accessibility and default value															

legend:

r bit is readable

rc this bit is cleared after a read

r,w bit is readable and writeable, reading yields the previously written value unless otherwise specified.

w bit is writeable, read value is undefined

wc writing a '1' to this bit clears it

w,0 bit is write-only, reading always yields 0.


0 default value

1.4 Trademarks

TI, Code Composer, DSP/BIOS and TMS320C6000 are registered trademarks of Texas Instruments.

Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Hyperterminal is a trademark of Hilgraeve Inc.

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 7
---	--	--

All other brand or product names are trademarks or registered trademarks of their respective companies or organizations.

1.5 Revision History

Revision	Changes
v1.0	First official release
v1.0a	Examples: BIOS configuration documented.

2 Introduction

This board support package allows to use the C6713Compact-2 as a conventional micro-line[®] CPU board. It defines the function of the signals on the micro-line[®] connector similar to those of other micro-line[®] CPU modules, such as the micro-line[®] C6211CPU board, providing an easy to use peripheral interface. Further, this BSP provides FIFO-buffered access to the data mover port of the IEEE1394 chipset for high speed IEEE1394 data streaming.

The functions provided on the micro-line[®] connectors are:

- micro-line[®] bus master signals as mentioned in [1] (reset outputs, external flag I/O, RS-232 interface, DSP peripherals). These signals are always present, independent of this BSP.
- micro-line[®] peripheral interface
- host port interface (HPI)

With the micro-line[®] peripheral interface, peripherals can be easily connected to the C6713Compact-2, using no or only minimal glue logic.

The HPI allows other CPUs to access the C6713Compact-2 as a peripheral (e.g. for inter-processor communication).

The software interface is similar to those of the C6x1xCPU and the SC1394a, so software can be easily ported from the micro-line[®] C6x1xCPU or the Complete II to the C6713Compact-2.

This BSP should be chosen for

- migration from previous micro-line[®] CPU modules to the C6713Compact-2
- migration from the micro-line[®] Complete II to the C6713Compact-2
- accessing micro-line[®] peripheral modules
- using the micro-line[®] peripheral interface to connect custom hardware
- software access to IEEE1394 streaming data
- connecting the C6713Compact-2 to a host CPU using the DSP's HPI.

This document describes the features of the BSP solely. The basic features (FPGA independent) of the C6713Compact-2 are documented in [1].

Please note: To use this BSP, the FPGA must first be loaded with the appropriate code. How to do this is shown in the application examples, see chapter 12.1.1.

3 Functional Overview




Figure 1: Block diagram of the busmaster BSP

3.1 *micro-line[®] Peripheral Interface*

The micro-line[®] peripheral interface provides a straightforward connection to up to seven peripheral boards or custom hardware devices without glue-logic. Its functionality is basically the same as the direct connection to the TMS320C6713 EMIF in asynchronous operation mode, or to the parallel bus of many other standard DSPs or micro-controllers. Each bus cycle consists of a setup, a strobe and a hold phase. Timing of each phase can be programmed to 1 to 15 EMIF clocks.

On the C6713Compact-2, the micro-line[®] peripheral interface basically consists of

- 32 data bus lines
- 24 address bus lines (only the lower 16 are actually used)
- 7 chip select lines
- 5 interrupt lines
- a number of control lines.

Connection examples for the micro-line[®] peripheral interface can be found in chapter 11.1.




Figure 2: micro-line® peripheral interface

Figure 2 gives an overview of the available signals and their direction. For a detailed description of the individual signals, please refer to chapter 8.1.

Chip select lines /CS1 ... /CS3 are mapped into CE space 2 of the TMS320C6713 DSP. This CE space is configured for 32-bit accesses by default. The remaining chip select lines /CS4 ... /CS7 are mapped into CE3, which is configured for 16-bit bus width by default. For further details on address mapping and bus width configuration, please refer to chapter 4.

Access cycles

The peripheral interface generates a 3-phase bus cycle, independent of the EMIF settings. The list below shows the steps being performed:

- When the peripheral interface is accessed, the DSPs ready line is deactivated to hold the current EMIF cycle until the peripheral interface has finished its access.
- At the beginning of the setup phase,
 - D[31:0] is driven with the current write data (for write accesses only)
 - A[23:16] stay driven low
 - A[15:0] are driven with the current address (with in the addressed chip select range)
 - The /CS output of the addressed chip select is driven low while the other /CS lines stay high
 - R/W is driven low for write cycles and high for read cycles
- The setup phase has a programmable width of 1 to 7 EMIF clocks, resulting in a setup period of 10 to 70 ns.

- The setup phase is followed by the strobe phase. At the beginning of the strobe phase,
 - /RD is driven low in case of a read cycle
 - /WR is driven low in case of a write cycle
 - /STRB is driven low
 - All other signals remain unchanged
- The strobe phase has a programmable width of 1 to 15 EMIF clocks, resulting in a strobe period of 10 to 150 ns.
- RDY is sampled 4 EMIF clocks before the end of the strobe phase, see chapter 10.1 for timing details. RDY allows slow peripherals to extend the strobe phase beyond 15 clocks.
- The strobe phase is followed by the hold phase. At the beginning of the hold phase,
 - read data is sampled (in case of a read cycle)
 - /RD, /WR and /STRB are driven high
- The hold phase has a programmable width of 1 to 15 EMIF clocks, resulting in a hold period of 10 to 150 ns.
- At the end of the hold phase,
 - D[31:0] are switched to high impedance
 - /CS[7:1] are all driven high (switching off the activated chip select line)
 - the ARDY line of the DSP is released so that the DSP can finish the current EMIF access cycle

Timing diagrams can be found in chapter 10.1.

The timing parameters of the peripheral interface can be adjusted by writing to the CSCTL register, see chapter 5.2.1.

Peripheral devices may extend the strobe phase of a peripheral interface access by hardware using the RDY input. This allows

- to access very slow peripherals, that require even slower timings than the peripheral interface supports
- to access slow peripherals with the correct timing, while faster peripherals are accessed with unexpanded bus cycles.

De-asserting the ready (RDY) input line of the micro-line[®] peripheral interface during an I/O access will keep the processor in a permanent wait-state as long as the RDY input line will remain inactive. Only the assertion of the RDY input line will finalize the pending I/O bus cycle and allow the processor to continue operation. If external hardware controlled I/O access timings are not required, the RDY input line of the micro-line[®] peripheral interface should be left unconnected.

How to access peripherals from application software is described in chapter 12.1.2.

3.2 Host Port Interface (HPI)




Figure 3: HPI block diagram

The TMS320C6713 DSP provides a 16 bit wide host port interface (HPI) which can be used by a host processor to directly access the memory of the DSP. Here, the host device accesses the HPI

as a master and the DSP acts as a slave. The host processor and the DSP can exchange information via DSP-internal and on-board memory. The host also has direct access to memory-mapped peripheral registers of the DSP. Connectivity to the DSP memory space is automatically provided through a DMA mechanism. The host device controls the HPI transfers via dedicated HPI address and data registers which are not accessible for the DSP. Here, the DMA auxiliary channel connects the HPI to the DSP memory space.

Both, the host and the DSP can access the HPI control register (HPIC). The host can access the HPI address register (HPIA), the HPI data register (HPID) and the HPIC by using the external host port data and control signals. The host can also access the HPI data register in an auto-increment mode (HPIDA), which allows to read a contiguous block of data without writing to the HPIA register each time.

The TMS320C6713 can trigger interrupts on the host processor to initiate data transfers. This avoids unnecessary status polling by the host processor.

The host port data and control signals are available on the micro-line[®] bus at connector BB. Host port byte accesses are not supported. Therefore no byte select control signal is provided on the micro-line[®] bus. Furthermore no multiplexed data and address busses are supported. The DSP's control signal /HAS is not used.

The FPGA connects the HPI signals from the micro-line connectors to the DSP's HPI using combinational logic, adding some delay. The resulting host port timings of the C6713Compact-2 are described in chapter 10.2. Further details about TMS320C6713 HPI can be found in [11].




Figure 4: Available HPI signals

The host port interface on the micro-line[®] connectors consists of the following signals:

Signal	description	associated with DSP signal
HD0...HD15	host port data bus (input/output)	HD[15:0]
HA0...HA2	host port address bus (input)	HHWIL, HCNTL[1:0]
/HCS	host port chip select (input)	/HCS
/HRD	host port read strobe (input)	/HDS[2:1] (read access only)
/HWR1	host port write strobe (input)	/HDS[2:1] (write access only)
HR/W	host port read/write select (input)	HR/W
HRDY	host port ready (output)	HRDY
/HINT	host port interrupt (output)	/HINT

Table 1: HPI signals

There are two different host port hardware operation modes possible. The first one allows to connect a host with separate strobe signals to the board, using the signals /HCS (chip select), /HRD (read) and /HWR (write), while HR/W (read/write) must also be connected to /HWR. The second one allows to connect a host with common strobe to the board, using the signals /HCS (chip select), HR/W (read/write) and a strobe signal, which must be connected to both, /HRD, while /HWR must be connected to 1. Chapter 11.2 contains connection examples.

HPI control signal				Access type
/HCS	/HRD	/HWR	/HR/W	
0	0	0	0	ignored
0	0	0	1	ignored
0	0	1	0	write access (common strobe configuration)
0	0	1	1	read access (both configurations)
0	1	0	0	write access (separate strobe configuration)
0	1	0	1	ignored
0	1	1	0	ignored
0	1	1	1	ignored
1	x	x	x	ignored

Table 2: Valid HPI access combinations

The functions of the host port addresses are specified in Table 3:

Address			Description
HA2	HA1	HA0	
0	0	0	host port interface control register (HPIC), 1 st halfword
0	0	1	host port interface control register (HPIC), 2 nd halfword
0	1	0	host port interface address register (HPIA), 1 st halfword
0	1	1	host port interface address register (HPIA), 2 nd halfword
1	0	0	host port interface data register with auto increment (HPIDA), 1 st halfword
1	0	1	host port interface data register with auto increment (HPIDA), 2 nd halfword
1	1	0	host port interface data register (HPID), 1 st halfword
1	1	1	host port interface data register (HPID), 2 nd halfword

Table 3: HPI registers

The HPI data are only driven in the respective direction when a valid access is detected. This helps to avoid bus contention.

3.3 IEEE1394 Data Streaming

The IEEE1394 chipset of the C6713Compact-2 provides a direct access to IEEE1394 data through the data mover port of the link layer controller (LLC). The data mover port can operate in parallel with software accesses to the LLC's microcontroller interface. Data transfers are buffered by an 8Kbyte FIFO. The DSP accesses FIFO data through the STR_DATA register; see chapter 5.1 for details.




Figure 5: IEEE1394 data streaming block diagram

The default transfer method for data streaming is isochronous streaming (see [24] for details). The FPGA can be set up to receive data payload only (from the LLC), so that user data can be transferred transparently without the need to insert or remove protocol information into or from the data stream. On the other hand, the FPGA can be configured for complete packet information. This allows for example, synchronization information to be inserted into the data stream or to synchronize an incoming image data stream to a frame boundary. The respective data formats are shown in [4].

For setting up and controlling data streaming, the FPGA provides a set of registers. These are summarized in chapter 5.1 and described in detail in [4]. Please note that data streaming also requires set up of the LLC, which is usually done using the IEEE1394 embedded API [5]. How to set up isochronous streaming is shown in application example *isotst*. Please refer to chapter 12.1.4 and the example's source code for further information.

4 Address Map

4.1 C6713Compact-2 Address Map

The table below shows how the 4Gbyte address space of the C6713Compact-2 is used. From this address space, CE spaces CE2 and CE3 are used by the micro-line[®] busmaster BSP.

address range (hex)	CE space	size (bytes)	description
0000 0000 – 7FFF FFFF	none	2G	internal memory and on-chip peripherals
8000 0000 – 8FFF FFFF	CE0	256M	external memory (SDRAM)
9000 0000 – 9FFF FFFF	CE1	256M	on-board peripherals
A000 0000 – AFFF FFFF	CE2	256M	FPGA registers and micro-line [®] peripheral interface
B000 0000 – BFFF FFFF	CE3	256M	
C000 0000 – FFFF FFFF	reserved	1G	reserved

Table 4: C6713Compact-2 address map

4.2 Address Map of the micro-line[®] Busmaster BSP

The table below show, how the CE2 and CE3 address spaces are used by this BSP. Please note, that the addresses refer to the default EMIF configuration, where CE2 is configured for 32 bit accesses and CE3 is configured for 16-bit accesses.

address range (hex)	CE space	size (bytes)	description
A000 0000 – A000 003F	CE2	64	streaming port registers
A000 0040 – A003 FFFF		256K-64	reserved
A004 0000 – A007 FFFF		256K	micro-line [®] CS1 (32 bit)
A008 0000 – A00B FFFF		256K	micro-line [®] CS2 (32 bit)
A00C 0000 – A00F FFFF		256K	micro-line [®] CS3 (32 bit)
A010 0000 – A013 FFFF		256K	CSCTL register
A014 0000 – AFFF FFFF		255M-256K	reserved
B000 0000 – B001 FFFF	CE3	128K	reserved
B002 0000 – B003 FFFF		128K	micro-line [®] CS4 (16 bit)
B004 0000 – B005 FFFF		128K	micro-line [®] CS5 (16 bit)
B006 0000 – B007 FFFF		128K	micro-line [®] CS6 (16 bit)
B008 0000 – B009 FFFF		128K	micro-line [®] CS7 (16 bit)
B00A 0000 – B00F FFFF		384K	reserved
B010 0000 – B010 0007		8	FPGA registers
B010 0008 – BFFF FFFF		255M-8	reserved

Table 5: Default address map of this BSP

4.2.1 Bus Width Configuration

By default, the CE2 address space is configured for 32 bit bus width and CE3 is configured for 16 bit bus width. This configuration allows a wide range of peripherals to be connected and can be used in almost any cases.

However, in some special situations, it may be necessary to change the bus width, e.g. when

- more than three 32-bit chip select lines are needed (then CE3 must be configured to 32 bit, so that /CS[7:4] are also available for 32 bit peripherals)
- 8 bit peripherals are used and their registers must be accessible as a contiguous address space (then one of the CE spaces must be configured for 8 bit width)

Changing the bus width is done together with setting up EMIF timings, see chapter 6. When the bus width is changed, the address map (base addresses and size of the address range) also changes. The resulting addresses are listed in the following tables.

Please note that reconfiguration of the bus width can disable access to IEEE1394 data streaming or to the FPGA registers as shown in the tables below.

address range (hex)	CE space	size (bytes)	description
A000 0000 – A000 001F	CE2	32	reserved
A000 0020 – A001 FFFF		128K-16	reserved
A002 0000 – A003 FFFF		128K	micro-line [®] CS1 (8 bit)
A004 0000 – A005 FFFF		128K	micro-line [®] CS2 (8 bit)
A006 0000 – A007 FFFF		128K	micro-line [®] CS3 (8 bit)
A008 0000 – A009 FFFF		128K	reserved
A00A 0000 – AFFF FFFF		256M-640K	reserved

Table 6: Modified address map with CE2 configured for 16 bit

Usage notes:

- Each of CS1 ... CS3 is organized as 64K by 16 bit
- IEEE1394 data streaming is not possible (32-bit wide data register can't be accessed)

address range (hex)	CE space	size (bytes)	description
A000 0000 – A000 000F	CE2	16	reserved
A000 0010 – A000 FFFF		64K-16	reserved
A001 0000 – A001 FFFF		64K	micro-line [®] CS1 (8 bit)
A002 0000 – A002 FFFF		64K	micro-line [®] CS2 (8 bit)
A003 0000 – A003 FFFF		64K	micro-line [®] CS3 (8 bit)
A004 0000 – A004 FFFF		64K	reserved
A005 0000 – AFFF FFFF		256M-320K	reserved

Table 7: Modified address map with CE2 configured for 8bit

Usage notes:

- Each of CS1 ... CS3 is organized as 64K by 8 bit
- IEEE1394 data streaming is not possible in 8-bit mode
- Setting up timing of the peripheral interface must be done before changing bus width (CE2 must be configured for 16 or 32 bits)

address range (hex)	CE space	size (bytes)	description
B000 0000 – B003 FFFF	CE3	256K	reserved
B004 0000 – B007 FFFF		256K	micro-line [®] CS4 (16 bit)
B008 0000 – B00B FFFF		256K	micro-line [®] CS5 (16 bit)
B00C 0000 – B00F FFFF		256K	micro-line [®] CS6 (16 bit)
B010 0000 – B013 FFFF		256K	micro-line [®] CS7 (16 bit)
B014 0000 – B01F FFFF		768K	reserved
B020 0000 – B020 000F		16	FPGA registers
B020 0010 – BFFF FFFF		254M-16	reserved

Table 8: Modified address map with CE3 configured for 32 bit

Usage notes:

- Each of CS4... CS7 is organized as 64K by 32 bit
- FPGA registers are intersected with 16 bits of unused data

address range (hex)	CE space	size (bytes)	description
B000 0000 – B000 FFFF	CE3	64K	reserved
B001 0000 – B001 FFFF		64K	micro-line [®] CS4 (16 bit)
B002 0000 – B003 FFFF		64K	micro-line [®] CS5 (16 bit)
B003 0000 – B004 FFFF		64K	micro-line [®] CS6 (16 bit)
B004 0000 – B005 FFFF		64K	micro-line [®] CS7 (16 bit)
B005 0000 – B007 FFFF		192K	reserved
B008 0000 – B008 0003		4	FPGA registers
B008 0004 – BFFF FFFF		255.5M-4	reserved

Table 9: Modified address map with CE3 configured for 8 bit

Usage notes:

- Each of CS4... CS7 is organized as 64K by 8 bit
- Access to FPGA registers is limited. The following bit fields are no longer accessible:
 - Register VERSION, bit field VERSION
 - Register INT_CTL, bit field DM_INT

5 Register Description

5.1 IEEE1394 Streaming Registers

The registers used for IEEE1394 streaming are documented in [3]. One additional register provides access to streaming data. This register must always be accessed as 32 bits. The table below shows the register locations.

Register	Address (hex)	width
STR_CTL	A000 0000	16 bit
reserved	A000 0004	n/a
STR_HDR_L	A000 0008	16 bit
STR_HDR_H	A000 000C	16 bit
reserved	A000 0010	n/a
reserved	A000 0014	n/a
STR_AFL	A000 0018	16 bit
STR_AEL	A000 001C	16 bit
STR_IE	A000 0020	16 bit
STR_IF	A000 0024	16 bit
reserved	A000 0028	n/a
reserved	A000 002C	n/a
reserved	A000 0030	n/a
STR_LEVEL	A000 0034	16 bit
STR_DATA	A000 0038	32 bit
reserved	A000 003C	n/a

5.2 FPGA Registers

Table 10 lists the register addresses. Default configuration is listed in **bold**.

register	description	address		
		8 bit bus width	16 bit bus width	32 bit bus width
CSCTL	controls chip select timing	A004 0000h	A008 0000h	A010 0000h
VERSION	FPGA version	B008 0000h	B010 0000h	B020 0000h
LED_CTL	LED control	B008 0001h	B010 0002h	B020 0004h
CLK_CTL	controls clock output	B008 0002h	B010 0004h	B020 0008h
INT_CTL	interrupt polarity & selection	B008 0003h	B010 0006h	B020 000Ch

Table 10: FPGA register locations

Name	Addr.	15-10	9	8	7	6	5	4	3	2-0
CSCTL	A0100000	RESERVED		SETUP			STRB			HLD
VERSION	B0100000	VERSION			REVISION					
LED	B0100002	RESERVED			LED_GREEN	LED_RED	RESERVED			
EMIF_CLK	B0100004	RESERVED				CLK_EN	DIV		RESERVED	
INT_CTL	B0100006	RESERVED	STR_INTSEL	EINT7_POL		EINT6_POL	EINT5_POL	ENT4_POL	NMI_POL	RESERVED

Table 11: FPGA register bit summary in default EMIF configuration

5.2.1 Chip Select Control Register

This register controls timing of the peripheral interface.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RESERVED						SETUP		STROBE			HOLD				
r,0000000						r,w,001		r,w,001			r,w,001				

SETUP controls the number of EMIF clocks for the setup phase. Default value is 1 clock, a value of 0 is treated as a value of 1. Allowable range is 1 to 7.

STROBE controls the number of EMIF clocks for the strobe phase. Default value is 1 clock, a value of 0 is treated as a value of 1. Allowable range is 1 to 7.

HOLD controls the number of EMIF clocks for the hold phase. Default value is 1 clock, a value of 0 is treated as a value of 1. Allowable range is 1 to 7.

5.2.2 FPGA Version Register

This register describes the FPGA version and revision. Application software can use this register to check, if the correct FPGA code is loaded. This register is read-only.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
VERSION								REVISION							
r,00000011								r							

VERSION

This bit field describes the FPGA version. Each BSP has a unique version. This BSP uses version number 3. The version field can be used by application software to verify that the correct BSP is loaded.

REVISION

This bit field describes BSP revision. The revision can change due to product improvement.

5.2.3 LED Control Register

This register controls the two LEDs that are connected to the FPGA. The LEDs can be used as status indicators by application software, e.g.

- the green LED is switched on during signal processing to show activity
- the red LED can be switched on when errors are detected

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RESERVED								LED_GREEN		LED_RED		RESERVED			
r,00000000								r,w,0		r,w,0		r,000000			

LED_GREEN

This bit controls the green LED. Setting this bit to 1 will cause the green LED to light. By default, the green LED is off.

LED_RED

This bit controls the red LED. Setting this bit to 1 will cause the red LED to light. By default, the red LED is off.

5.2.4 Clock Control Register

This register controls the EMIF_CLK output on the micro-line® connector. This signal is generated from the DSP's EMIF clock. Please note that changing the EMIF_CLK on the micro-line® connector does not change the EMIF clock of the DSP. All timings based on the EMIF clock (such as SDRAM timings or the asynchronous timings of the seven micro-line® chip select lines) remain unchanged.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RESERVED								CLK_EN		DIV		RESERVED			
r,00000000								r							

CLK_EN

If this bit is set, the EMIF_CLK output is driven. If this bit is set to 0, the EMIF_CLK line is in high impedance state. This bit can be used to reduce EMI when EMIF_CLK if it is not used. Changing CLK_EN is synchronized to the clock output to allow glitch-free switching.

DIV

This bit field controls the frequency of the EMIF_CLK output. By default, DIV is set to 3, which selects a frequency of a quarter of the EMIF clock (25 MHz at a default EMIF clock of 100 MHz). Changing DIV is synchronized to the clock output to allow glitch-free switching. Together with CLK_EN, the following selections are possible:

CLK_EN	DIV	EMIF clock output
0	(don't care)	Z
1	0	0
	1	undivided EMIF clock
	2	$\frac{\text{EMIF clock}}{2}$
	3	$\frac{\text{EMIF clock}}{4}$

Table 12: Possible EMIF_CLK settings

5.2.5 Interrupt Control Register

This register has two purposes:

- it controls the polarity for the interrupt sources on the micro-line[®] bus
- it selects the interrupt line that is used for IEEE1394 data streaming.

15-10	9	8	7	6	5	4	3	2-0
RSV	STR_INTSEL	EINT7_POL	EINT6_POL	EINT5_POL	EINT4_POL	NMIPOL	RSV	
r,000000	r,w,00				r,w,00000			r,000

STR_INTSEL

This bit field selects the interrupt line for streaming. Default value is 0, so DSP external interrupt 4 is used.

STR_INTSEL	interrupt line
0	EXT_INT4
1	EXT_INT5
2	EXT_INT6
3	EXT_INT7

EINT4_POL ... EINT7_POL, NMI_POL

These bits control the polarity of the interrupt inputs at the micro-line[®] connector. This gives the user more flexibility in connecting peripherals to the C6713Compact-2. By default, all bits are 0, which selects falling edge triggered interrupts (in contrast to the DSP interrupts, which are rising edge triggered by default). If an interrupt source with rising edge triggered interrupts is connected to the micro-line[®] bus, the corresponding polarity bit needs to be set. Please do not change the interrupt polarity in the DSP's registers. The micro-line[®] interrupts trigger the corresponding interrupts on the DSP. However, some more interrupt sources exist on the C6713Compact-2. Therefore, application software must check all possible interrupt sources. The other interrupt sources are described in [1].

EINTx_POL, NMI_POL	micro-line [®] interrupts
0	falling edge triggered
1	rising edge triggered

6 Setting up EMIF Timings

This chapter shows how the EMIF must be set up for using the micro-line[®] busmaster BSP.

By default, the Flash File System sets up the EMIF timings for the CE2 and CE3 address space to a slow and safe default. This default works with the micro-line[®] busmaster BSP, however, using the default setting does not give optimum performance, so the user may want to modify EMIF settings. How to program this is shown in the examples on the distribution media and in the board library documentation. The actual timings depend on which parts of the BSP are being used.

There is an absolute minimum, which can be used for register accesses only, excluding the peripheral interface and streaming data. When using this setup, accesses to the FPGA may include a one-clock wait cycle which slows down operation.

There is also a recommended minimum, which allows register accesses without wait states and also allows accessing the peripheral interface (which always inserts waitstates).

For reading streaming data from the FIFO, the entire cycle time must be increased by 1 clock to allow FIFO data to update in time when doing back-to-back read cycles.

Table 13 lists the default timings set up by the Flash File System and the timings required for operation of the micro-line[®] busmaster BSP.

parameter	Required setting in EMIF clocks			
	FFS default	Absolute minimum	Recommended minimum / peripheral interface	Streaming
read setup	5	1	2	3
read strobe	25	2	2	2
read hold	3	1	1	1
turnaround	1	1	1	1
write setup	5	1	2	2
write strobe	25	2	2	2
write hold	3	1	1	1

Table 13: Timings for the CE2 and CE3 address spaces

Note: Setting up EMIF timings is done together with setting up the memory type, which in turn defines the actual bus width.

7 Signals on the micro-line Connector

This chapter lists the signals on the micro-line[®] connectors that are defined by this BSP. For a description of the remaining signals and connector locations, please refer to [1]. Entries labeled "RSV" are connected to the FPGA but are not used. They have pull-up termination in the FPGA. Shaded entries are provided by basic board hardware, independent of the micro-line[®] busmaster BSP.

Pin	Connector					
	A	B	BB	C	D	E
1	D0 (I/O/Z)	A0 (O)	HD0 (I/O/Z)	RSV	Power GND (I)	RSV
2	D1 (I/O/Z)	A1 (O)	HD1 (I/O/Z)	RSV	Power GND (I)	RSV
3	D2 (I/O/Z)	A2 (O)	HD2 (I/O/Z)	RSV	Power GND (I)	RSV
4	D3 (I/O/Z)	A3 (O)	HD3 (I/O/Z)	RSV	Power GND (I)	RSV
5	D4 (I/O/Z)	A4 (O)	HD4 (I/O/Z)	RSV	+3.3 to +5V (I)	RSV
6	D5 (I/O/Z)	A5 (O)	HD5 (I/O/Z)	RSV	+3.3 to +5V (I)	RSV
7	D6 (I/O/Z)	A6 (O)	HD6 (I/O/Z)	RSV	/RESETIN (I)	RSV
8	D7 (I/O/Z)	A7 (O)	HD7 (I/O/Z)	RSV	/RESETOUT (O)	RSV
9	D8 (I/O/Z)	A8 (O)	HD8 (I/O/Z)	RSV	RESETOUT (O)	RSV
10	D9 (I/O/Z)	A9 (O)	HD9 (I/O/Z)	RSV	/CS1 (O)	DR1 (I)
11	D10 (I/O/Z)	A10 (O)	HD10 (I/O/Z)	RSV	/CS2 (O)	DX1 (O/Z)
12	D11 (I/O/Z)	A11 (O)	HD11 (I/O/Z)	RSV	/CS3 (O)	CLKR1 (I/O/Z)
13	D12 (I/O/Z)	A12 (O)	HD12 (I/O/Z)	RSV	/CS4 (O)	CLKX1 (I/O/Z)
14	D13 (I/O/Z)	A13 (O)	HD13 (I/O/Z)	RSV	/CS5 (O)	FSR1 (I/O/Z)
15	D14 (I/O/Z)	A14 (O)	HD14 (I/O/Z)	RSV	/CS6 (O)	FSX1 (I/O/Z)
16	D15 (I/O/Z)	A15 (O)	HD15 (I/O/Z)	RSV	/CS7 (O)	CLKS1 (I)
17	D16 (I/O/Z)	A16 (O)	HA0 (I)	RSV	/EXT_INT4 (I)	TINP1 (I)
18	D17 (I/O/Z)	A17 (O)	HA1 (I)	RSV	/EXT_INT5 (I)	TINP0 (I)
19	D18 (I/O/Z)	A18 (O)	HA2 (I)	RSV	/EXT_INT6 (I)	CLKS0 (I)
20	D19 (I/O/Z)	A19 (O)	RSVD	RSV	/EXT_INT7 (I)	DR0 (I)
21	D20 (I/O/Z)	A20 (O)	HR/W (I)	RSV	/NMI (I)	DX0 (O/Z)
22	D21 (I/O/Z)	A21 (O)	/HCS (I)	RSV	/RD (O)	CLKR0 (I/O/Z)
23	D22 (I/O/Z)	A22 (O)	/HRD (I)	RSV	/WR (O)	CLKX0 (I/O/Z)
24	D23 (I/O/Z)	A23 (O)	/HWR (I)	RSV	R/W (O)	FSR0 (I/O/Z)
25	D24 (I/O/Z)	Signal GND	HRDY (O/Z)	RSV	/STRB (O)	FSX0 (I/O/Z)
26	D25 (I/O/Z)	Signal GND	/HINT (O/Z)	RSV	TXD (O)	XF0 (I/O/Z)
27	D26 (I/O/Z)	Signal GND	RSV	RSV	RTS (O)	XF1 (I/O/Z)
28	D27 (I/O/Z)	Signal GND	RSV	RSV	RXD (I)	TOUT0 (O)
29	D28 (I/O/Z)	Signal GND	RSV	RSV	CTS (I)	TOUT1 (O)
30	D29 (I/O/Z)	Signal GND	RSV	RSV	RDY (I)	UART_CLK (O/Z)
31	D30 (I/O/Z)	Signal GND	RSV	RSV	/HOLD (I)	EMIF_CLK (O/Z)
32	D31 (I/O/Z)	Signal GND	RSV	RSV	/HOLDA (O/Z)	/SHZ (I)

Table 14: Pinout of micro-line[®] connectors A through E

Pin	Connector X
1	RSV
2	RSV
3	RSV
4	RSV
5	RSV
6	RSV
7	RSV
8	RSV
9	RSV
10	RSV

Table 15: Pinout of micro-line[®] connector X

8 Individual Signal Description

This chapter describes each signal that is defined by the micro-line[®] busmaster BSP. The remaining signals (shaded entries in Table 14) are described in the C6713Compact-2 hardware reference guide [1].

8.1 *micro-line* Peripheral Interface

8.1.1 Connector A

D[31:0]:

These are the bi-directional data bus lines of the micro-line[®] peripheral interface. They are activated during the strobe phase of an access to the micro-line[®] peripheral interface. When inactive, the data bus is in high impedance state.

8.1.2 Connector B

A[15:0]:

These are the address bus output lines of the micro-line[®] peripheral interface. They are always active and carry a valid address during the entire access cycle, from start of setup phase until end of hold phase.

A[23:16]:

These address lines are not used in this BSP. They are always driven low by the FPGA.

8.1.3 Connector D

/CS[7:1]:

These are the seven active low chip select output lines of the micro-line[®] peripheral interface. They pre-select, which external peripheral component is accessed and are valid during all three phases of the access, from start of setup phase until end of hold phase. The seven peripheral address spaces are located in the processor's CE2 and CE3 address spaces. The chip select lines /CS1.../CS3 refer to the EMIF CE2 area of the processor and /CS4.../CS7 refer to the EMIF CE3 area of the processor. This allows to connect two different I/O areas with different bus width. The locations of the seven peripheral address spaces are shown in chapter 4.2.

/RD, /WR:

These are the active low read strobe (/RD) and write strobe (/WR) output lines of the micro-line[®] peripheral interface. They indicate a read cycle (/RD) or a write cycle (/WR). The strobe signals are active during the strobe phase of an access. In case of a read cycle, data is sampled at the rising edge of /RD. Write data is valid throughout the entire access cycle, from start of setup phase until end of hold phase. These signals should be used, when separate read and write strobes are required. Peripherals with a common strobe and a direction select signal should be used with R/W and /STRB instead.

R/W, /STRB:

These are the read/write (R/W) and the active low strobe (/STRB) output lines of the micro-line[®] peripheral interface. They indicate a read cycle (R/W = high and /STRB = low) or a write cycle (R/W = low and /STRB = low). R/W is valid throughout the entire access cycle, from start of setup phase until end of hold phase. /STRB is valid during the strobe phase of an access. These signals should be used to connect peripherals that require a common strobe signal and a direction select signal. Peripherals with separate read and write strobes should be used with /RD and /WR instead.

RDY:

This pin is the active high ready input of the micro-line[®] peripheral interface. RDY is sampled 4 clocks before the end of the strobe phase. If RDY is sampled low, the strobe period is extended by one EMIF clock and RDY is sampled again. If RDY is sampled high, the strobe period ends. If no bus cycle extension is required, RDY should be left unconnected. The necessary pull up resistor is provided on the C6713Compact-2. This input can be used by

- very slow hardware, whose timing exceeds the maximum timing adjustable in the CSCTL register
- a mixture of fast and slow peripherals, where the access timing is configured (in CSCTL) for the fast peripherals, but the slow peripherals can extend the access for their timing requirements. This way, the slow peripherals don't slow down accesses to the fast ones.

/HOLD, /HOLDA

These signals can be used by an external busmaster, to access on-board peripherals. The busmaster function is not supported by this BSP. Therefore, these signals should be left unconnected.

/EXT_INT[7:4]:

These are the four maskable interrupt input lines of the micro-line[®] peripheral interface. They can be used as interrupts or for DMA synchronization. In default configuration, all interrupts are triggered on the falling edge of the interrupt signal (in contrast to the default polarity of the DSP interrupt lines). They can be individually configured to be either falling edge triggered or rising edge triggered. This is described in chapter 5.2.5. Level triggering is not possible at the TMS320C6713 DSP. To enable interrupts from the micro-line[®] peripheral interface, the interrupts must be enabled by the DSP. Further, /EXT_INT6 and /EXT_INT7 are routed over the PLD of the C6713Compact-2 and must also be enabled there. This is described in [1]. The line status of /EXT_INT7 and /EXT_INT6 can be polled by PLD status bits, see also [1] for a description.

Please note, that other interrupt sources exist on the C6713Compact-2 for /EXT_INT6 and /EXT_INT7. Before designing peripheral hardware to use a specific micro-line[®] interrupt, please check which on-board interrupt sources of the C6713Compact-2 are used. Shared interrupts can be used, but avoiding them makes the system easier and faster.

/NMI:

This is the non-maskable interrupt input line of the micro-line[®] peripheral interface. Activation of /NMI causes an interrupt at a high priority level which can not be masked by software. In default configuration, /NMI is triggered on the falling edge of the interrupt signal (in contrast to the DSP's NMI signals, which is rising edge triggered). It can be configured to be either falling edge triggered or rising edge triggered. This is described in chapter 5.2.5. Level triggering is not possible.

RESETOUT and /RESETOUT:

These signals are always provided by the C6713Compact-2, independent of this BSP. Please refer to [1] for a description.

/HOLD, /HOLDA


8.1.4 Connector E

UART_CLK:

This signal is always provided by the C6713Compact-2, independent of this BSP. Please refer to [1] for a description.

EMIF_CLK:

This pin is the clock output for the micro-line[®] peripheral interface. This clock is generated from the DSP's external memory interface clock. The clock output on this pin is software programmable. By default, the DSP EMIF clock divided by 4 is available on this signal. See chapter 5.2.4 for details. In order to reduce EMI it is recommended to switch off this signal if it is not used. The clock output

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 25
---	--	---

has small delay to the DSP's EMIF clock and switches at the same time as all other outputs of the peripheral interface, see section 10.1 for timing specifications. Please note, that the frequency of this signal does not affect any timing of the TMS320C6713 EMIF.

8.2 Host Port Interface

8.2.1 Connector BB

HD[15:0]:

These pins are the bi-directional data bus of the host port interface. Data can be directly written to or read from the whole address space of the TMS320C6713 DSP. The data lines are only activated when a valid host port access is detected see Table 2. Otherwise, HD[15:0] are in high impedance state.

HA[2:0]:

These pins are the host port address inputs. They select which 16 bit halfword and which HPI register is currently accessed by the host. The register map of the host port is given in Table 3. Connection examples for the host port can be found in chapter 11.2.

/HCS:

This pin is the chip select input of the host port. The host must set /HCS low in order to enable host port accesses. /HCS must be low during the whole access.

/HRD:

This pin is the read strobe input of the host port. It should be connected either to the host's read strobe, or to the host's common strobe. Please refer to HPI access decoding in Table 2 and the connection examples in chapter 11.2 for details.

/HWR:

This pin is the write strobe input of the host port. It should be connected either to the host's write strobe, or to a permanent high level when using a common strobe. Please refer to HPI access decoding in Table 2 and the connection examples in chapter 11.2 for details.

HR/W:


This pin is the host read/write select input. The host must set HR/W high in order to read and low in order to write on the HPI. A host without a read/write select output can connect HR/W to /HWR or use an address line for this function. Please refer to HPI access decoding in Table 2 and the connection examples in chapter 11.2 for details.

HRDY:

This pin is the ready output of the host port. When active (high), HRDY indicates that the HPI is ready for a transfer to be performed. When inactive (low), HRDY indicates that the HPI is busy completing a read access, a previous HPI data register read pre-fetch or a write access. HRDY is always high when /HCS is high. Please note that HRDY is inverted with respect to the DSP's low-active ready output.

/HINT:

This pin is the interrupt output of the host port interface. This interrupt is controlled by the HINT bit in the HPI control register. It is cleared (set to high level) when the processor is reset. The TMS320C6713 DSP can trigger an interrupt to the host by setting the HINT bit in the HPIC register. An interrupt is pending, when /HINT is low. The host can clear the interrupt after processing by writing a 1 to the HINT bit.

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 26
---	--	---

8.3 Other Signals

/SHZ

Test pin for factory tests. When /SHZ is activated (driven low), below listed micro-line® pins are switched to high impedance state:

D[31:0], A[23:0], /CS[7:1], /RD, /WR, R/W, /STRB, EMIF_CLK, HRDY, /HINT, /HOLDA.

The /SHZ input is not designed for use during normal operation and should be left unconnected. A pull up resistor is implemented by the FPGA.

RSV

Signals listed as 'RSV' in Table 14 and Table 15 are FPGA I/O pins not used by this BSP. The FPGA pulls these pins high (regardless whether the FPGA is configured or not). Customers should leave these pins unconnected.

9 Signal Levels

All signals described in this document use LVTTTL signal levels. The recommended operating conditions are listed below:

parameter	value	
	min	max
logic low input voltage	-0.5 V	0.8 V
logic high input voltage	2.0 V	3.6 V
logic low output voltage ¹		0.4 V
logic high output voltage	2.4 V	

Table 16: Recommended operating conditions

¹ at 8mA load (12mA for EMIF_CLK)

10 Signal Timings

All timing specifications in this chapter apply to FPGA version 3.0. The timings are based on the FPGA design and also include some margin for PCB trace delay.

10.1 micro-line Peripheral Interface

All inputs and outputs of the micro-line peripheral interface are synchronized to the EMIF clock. This gives a well-defined timing with minimum skew.

Parameter	min	max
EMIF_CLK valid after rising edge of DSP's ECLKOUT	2 ns	5 ns
all other outputs valid after rising edge of DSP's ECLKOUT	2 ns	6 ns
read data setup relative to rising edge of /STRB, /RD, /WR	8.1 ns	
read data hold relative to rising edge of /STRB, /RD, /WR	-2 ns	
RDY setup relative to rising edge of /STRB, /RD, /WR	48 ns	
RDY hold relative to rising edge of /STRB, /RD, /WR	-42 ns	
delay from /EXT_INT[7:4], /NMI to DSP interrupts		23 ns
delay between DSP and /HOLD, /HOLDA		23 ns
Total EMIF cycle time for 1-1-1 (setup-strobe-hold) access	120 ns	
Total EMIF cycle time for 7-7-7 access, immediate ready	300 ns	
Total EMIF cycle time for 7-7-7 access, 1 clock not-ready	310 ns	

Table 17: Peripheral interface timings

10.2 Host Port Interface

The host port interface is handled by pure combinational logic. Therefore the timings of the DSP's HPI must be considered in conjunction with the timings specified below.

Parameter	min	max
Delay HPI strobe signals from connector to DSP	7.4 ns	15 ns
Skew between strobe signals		3.5 ns
Delay HPI select signals from connector to DSP	7.5 ns	14.6 ns
Skew between select signals		3.0 ns
HPI data tristate delay from connector to DSP	8 ns	17 ns
HPI data delay from connector to DSP	6.3 ns	13 ns
Skew between HPI data (connector to DSP)		2.5 ns
HPI data tri-state delay from connector to connector	5.5 ns	16 ns
HPI data delay from DSP to connector	6.3 ns	13 ns
Skew between HPI data (DSP to connector)		2.5 ns
Delay HRDY from DSP to connector	8 ns	13 ns
Delay /HINT from DSP to connector	9.2 ns	14.5 ns

Table 18: HPI Timings (FPGA part only)

11 Connection Examples

11.1 Peripheral Interface

Peripheral devices can be easily connected to the micro-line® peripheral interface of the C6713Compact-2. An example of connecting the 16C550 UART to the C6713Compact-2 is shown below. For this connection example,

- /EXT_INT4 must be configured to be rising-edge triggered, see section 5.2.5,
- timing of the peripheral interface must be set up to 2 clocks setup, 4 clocks strobe and 2 clocks hold, see 5.2.1 and
- the high-active reset output must be used.




Figure 6: Peripheral interface connection example

11.2 Host Port Interface

A master device (e.g. another CPU) can be easily connected to the host port interface of the C6713Compact-2. Depending on the host processor, two different connections variants are possible which will be shown below. Note: TI describes the host port timing behavior in [8], [10] and [15]. Please be sure to fulfill the timing requirements described in these documents.

11.2.1 Host Port Connection with Common Strobe and Direction Select

An example for connecting a CPU with common strobe signal to the C6713Compact-2 is shown below.




Figure 7: Host port connections when using a single strobe

The following steps have to be performed:

- All signals must be connected directly to the respective signal of the C6713Compact-2 except /STRB which must be connected to /HRD.
- /HWR must be pulled high.
- HRDY might need to be inverted, depending on the host CPU type.
- Address offset between HPI registers depends on the host CPU type.

The host CPU uses the following address map:

Address	Register
Base + 00	host port interface control (HPIC), 1st halfword
Base + 01	host port interface control (HPIC), 2nd halfword
Base + 02	host port interface address (HPIA), 1st halfword
Base + 03	host port interface address (HPIA), 2nd halfword
Base + 04	host port interface data with auto increment (HPIDA), 1st halfword
Base + 05	host port interface data with auto increment (HPIDA), 2nd halfword
Base + 06	host port interface data (HPID), 1st halfword
Base + 07	host port interface data (HPID), 2nd halfword

Table 19: HPI register address map

11.2.2 Host Port Connections with Separate Strobe Signals

An example for connecting a CPU with separate strobe signals to the C6713Compact-2 is shown below.




Figure 8: Host port connections when using separate strobe signals

The following steps have to be performed:

- All signals must be connected directly to the respective signal of the C6713Compact-2.
- HR/W must also be connected to the hosts /WR output.
- HRDY might need to be inverted, depending on the host CPU type.
- Address offset between HPI registers depends on the host CPU type.
- Register address map is the same as shown in Table 19

11.2.3 Host Port Connections with Separate Strobe Signals Alternative Method

If timing issues prohibit the use of the host's /WR signal, HR/W can also be connected to the host's /OE output (if present) or to an additional address bit. table below shows the resulting register address map when using the host's A3 line for direction selection.

CAUTION:

When connecting an address bit to HR/W, invalid accesses can cause bus contention on HD[15:0]! Please make sure that the register address corresponds with the access direction!




Figure 9: Host port connections when using address bit for direction selection

Address	Direction	Register
Base + 00	write only	host port interface control (HPIC), 1st halfword
Base + 01		host port interface control (HPIC), 2nd halfword
Base + 02		host port interface address (HPIA), 1st halfword
Base + 03		host port interface address (HPIA), 2nd halfword
Base + 04		host port interface data with auto increment (HPIDA), 1st halfword
Base + 05		host port interface data with auto increment (HPIDA), 2nd halfword
Base + 06		host port interface data (HPID), 1st halfword
Base + 07		host port interface data (HPID), 2nd halfword
Base + 08	read only	host port interface control (HPIC), 1st halfword
Base + 09		host port interface control (HPIC), 2nd halfword
Base + 10		host port interface address (HPIA), 1st halfword
Base + 11		host port interface address (HPIA), 2nd halfword
Base + 12		host port interface data with auto increment (HPIDA), 1st halfword
Base + 13		host port interface data with auto increment (HPIDA), 2nd halfword
Base + 14		host port interface data (HPID), 1st halfword
Base + 15		host port interface data (HPID), 2nd halfword

Table 20: HPI register address map using address bit for direction select

12 Application Examples

The following application examples are provided with the micro-line[®] busmaster BSP:

<code>toggle_led</code>	Basic example which is also the default application in FFS; placed in the BSP for historical reasons only.
<code>toggle_led_fpga</code>	Toggles all four user controllable LEDs (2x PLD and 2x FPGA) and shows how to configure (load) the FPGA
<code>asynctst</code>	Shows how to implement IEEE1394 asynchronous transactions
<code>isotst</code>	Shows how to implement IEEE1394 isochronous streaming

12.1 Default FFS Application (*toggle_led*)

This application example is not really specific to the micro-line[®] busmaster BSP. It was put into the BSP distribution for historical reasons. *toggle_led* is the default application that is stored in the FFS during production. It simply enables CTS resets (for connecting with the FFS utilities) and toggles the red LED.

12.1.1 Loading and Accessing the FPGA (*toggle_led_fpga*)

The distribution media contains an application example called *toggle_led_fpga*. This example shows

- How to load the FPGA from within application software using the board library
- How to access the FPGA registers (using the LED control register).

Please note: The FPGA can also be loaded through the Flash File System, see [2] for details.

To start this example you have to

- Connect the RS-232 interface of the C6713compact-2 to your development PC.
- Load the *toggle_led_fpga* example to the C6713Compact-2 using the *fload6x* utility. How to do this is described in the "Getting started" section of the respective development kit user's guide and also in [2]
- power-off the C6713Compact-2
- Start a terminal program, such as *Hyperterminal*
- power-on the C6713Compact-2
- Now you see the startup message of *toggle_led_fpga* in the terminal window and the LEDs of the C6713Compact-2 start to toggle.

C6713Compact-2 application example toggle_led_FPGA Feb 12 2012 15:55:58

FPGA loaded

Figure 10: Startup message of *toggle_led_fpga*

This example contains two modules: *toggle_led_fpga.c* which contains example code itself and the FPGA code for the micro-line[®] busmaster BSP which is contained in *ml_bm_fpga_lx<DEV>.c*, where <DEV> is for the respective FPGA type, e.g. 75 for an LX75.

The project that builds the example has different configurations, one for each supported FPGA type. The generated code is therefore specific to a certain FPGA type.

12.1.2 Micro-line[®] Peripheral Interface

There is no specific application example for accessing peripherals, because it would require some peripheral connected to the C6713Compact-2. However, accessing peripherals is straightforward and is described below:

The base addresses of each chip select are defined in C-headers that are delivered together with the C6713Compact-2. To access a peripheral device consider the following example:

- A peripheral device is connected to /CS1.
- Two locations are decoded by using the micro-line® address bus:

A0 = 0: control and status register, 8 bit wide, D0 indicates data is available

A0 = 1: data register, 16 bit wide

/CS1 is located within the CE2 address space, which is by default configured for 32 bit wide memory. Therefore, each address within /CS1 contains 32 bits and the (DSP) address offset between subsequent locations is 4 bytes. The code example below shows how to define access macros to the peripheral and how to access the peripheral.

```
#include "C6713Cpt-2_ml_bm.h" /* micro-line busmaster BSP definitions */

#define MY_CSR (*(volatile char *) (C6713Cpt_CS1_BASE + 0))
#define MY_DATA (*(volatile short *) (C6713Cpt_CS1_BASE + 4))

if (MY_CSR & 1) /* check some status bit for data availability */
    *pData++ = MY_DATA; /* read some data */
```

12.1.3 General IEEE1394 Operation (asynctst)

The distribution media of development kits with IEEE1394 support contains an application example called *asynctst*. This example shows how to do incoming and outgoing asynchronous transactions. An overview of asynchronous transactions can be found in [5]. The user interface of the application example is realized over the RS-232 interface. A terminal (e.g. a PC running *Hyperterminal*) must be connected to the RS-232 interface.

Please note that this application example does not depend on the micro-line® busmaster BSP. It can also run on the basic board hardware, without the FPGA being loaded.

To start this example you have to

- Connect the RS-232 interface of the C6713Compact-2 to your development PC.
- Load the *asynctst* example to the C6713Compact-2 using the fload6x utility (see [2]).
- Power-off the C6713Compact-2
- Start a terminal program, such as *Hyperterminal*
- Power-on the C6713Compact-2
- Now you see the startup message of *asynctst* in the terminal window and the red LED of the C6713Compact-2 starts to toggle.

asynctst consists of 3 modules:

- *asynctst.c* contains initialization, command interpreter, main loop and the asynchronous transactions
- *init.c* contains initialization of the C6713Compact-2
- *cfgrom.c* IEEE1394 configuration ROM contents for this example

The example initializes the C6713Compact-2, reads the board serial number from the EEPROM and initializes the IEEE1394 API. API operation is started and an address range for incoming transactions is allocated. Then, a main loop is entered. The main loop handles bus resets and user commands from RS-232. Supported commands are:

1, 2 or 4:	set the speed to S100, S200 or S400
b	generate a bus reset
c	switch between counter data and random data
l	list available IEEE1394 devices
s	set up remote device and packet size
r	reset random number generator
h or ?	display help page
(all others)	start a data transfer

Incoming transactions are displayed using the notification callback for the allocated address range. Outgoing transactions are triggered by the user over the RS-232 interface by pressing any unallocated key, e.g. the space bar. A packet with random data or counter data is then sent to the remote device using an asynchronous write transaction. Then the packet is read back using an

asynchronous read transaction. Finally, the data written to the remote device is compared to the data that was read back.

Figure 11 shows a sample session where

- the start up message is shown
- an outgoing asynchronous transaction sequence to the default remote device is started which results in an error response
- *asynctst* is set up to address another remote device and to use the maximum packet size.
- a second outgoing asynchronous transaction sequence (write + read back) is started which is done successfully
- an incoming asynchronous transaction (read access from the remote device) with 10 quadlets = 40 (28h) bytes is displayed.

Note: When *asynctst* displays an address error, then the remote device does not allow incoming transactions on targeted address range (2048 bytes at address 0). This is the case when *asynctst* accesses the IEEE1394 interface of a PC where no special application is running. To enable this address range, you have to run a suitable application, e.g. another *asynctst*, running on another C6713Compact-2.



```
1394 embedded API test application
C6713Compact ASYNCTST Vr. 1.1 Nov 21 2003 18:38:00

CPU clock: 0225792000Hz
FPGA Version 003 revision 000: OK
HAL version: 17030523
API version: 17030523
Node vendor ID and serial number:00B02A00 000019AF

press '?' to get help page
BR

Bus reset #00000001
nodes on the network (own node has index 0):
idx cur. vendor ser.number status
   node      H   L
000 000 081443 53 0000166B present
001 001 00B02A 00 00001A15 present
o   002 00B02A 00 000019AF local node

press ? for help page, <space> to start a transaction
handle of remote node: 0003672C, vendor & S/N: 081443 53 0000166B
writing 0004 bytes response code: 7 (address error)
test setup

nodes on the network (own node has index 0):
idx cur. vendor ser.number status
   node      H   L
000 000 081443 53 0000166B present
001 001 00B02A 00 00001A15 present
o   002 00B02A 00 000019AF local node
select partner device for test (idx column): 1
adjust packet sizes new packet size in quadlets: 512
Quadlets per Packet: 0200
handle of remote node: 00036774, vendor & S/N: 00B02A 00 00001A15
writing 0800 bytes
reading 0800 bytes
comparing
done
NfY
W 0028 bytes addr 0000 node 001
NfY
R 0028 bytes addr 0000 node 001
```

Figure 11: Sample *asynctst* session

Modifications in the DSP/BIOS configuration files:

asynctst.cdb / .tcf is derived from *C6713CPT_225MHz_32MB.cdb / .tcf*

"Scheduling" → "HWI – Hardware Interrupt Service Routine Manager" → "HWI_INT6":

"function": _LynxHALNodeISR

"Dispatcher" → "Use Dispatcher": (not selected)

"Scheduling" → "TSK - Task Manager": Insert a task with the following properties:

"General" → "comment": task containing the main loop

"Function" → "Task function": _TASK_WorkingThread

task object renamed to: TSK_work

12.1.4 Software Streaming (*isotst*)

The distribution media contains an application example called *isotst*. This example shows how to do software streaming using isochronous transactions. An overview of isochronous transactions can be found in [5]. The user interface of the application example is realized over the RS-232 interface. A terminal (e.g. a PC running *Hyperterminal*) must be connected to the RS-232 interface. To start this example you have to

- Connect the RS-232 interface of the C6713Compact-2 to your development PC.
- Load the *isotst* example to the C6713Compact-2 using the *fload6x* utility (see [1]).
- Load the micro-line busmaster FPGA to the C6713Compact-2 using the *fpgaload* utility (see [1]).
- Power-off the C6713Compact-2
- Start a terminal program, such as *Hyperterminal*

- Power-on the C6713Compact-2
- Now you see the startup message of *isotst* in the terminal window.

isotst consists of 3 modules:

- *isotst.c* contains initialization, command interpreter, main loop and the asynchronous transactions
- *init.c* contains initialization of the C6713Compact-2
- *cfgrom.c* IEEE1394 configuration ROM contents for this example

The example initializes the C6713Compact-2 with the minimum allowed EMIF timing, so that software streaming can be performed with maximum speed. The FPGA is checked to be present (previously loaded from FFS). The board serial number is read from the EEPROM and the IEEE1394 API is initialized. API operation is started and a main loop is entered. The main loop handles user commands from RS-232.

b	generate a bus reset
c	switch between counter data and random data
h or ?	display help page
i	initialize packet data (random number generator and counter)
r	receive one data block
R	Receive continuously
t	transmit one block
T	transmit continuously

Pressing the 's' key on the terminal starts an interactive setup. Here, the speed and size of a single isochronous packet can be set up as well as the frame size, which determines the number of packets that are transferred as a contiguous sequence.

The example is optimized for transmit speed by implementing QDMA transfers and single-stage pipelining, where test data generation, QDMA transfers and transmit form the FPGA's FIFO buffer can run in parallel.

Figure 27 shows a sample session where *isotst* is set up for a frame of 10 packets with maximum size and then a single transmission is started.

```

1394 embedded API test application
C6713Compact ISOTST Vr. 1.1 Nov 21 2003 18:49:38
CPU clock: 0227174400Hz
FPGA Version 003 revision 000: OK
HAL version: 17030523
API version: 17030523
Default packet size is 0001h quadlets,
Default frame size is 0001h quadlets,
Default speed is S100
Node vendor ID and serial number:00B02A00 000019AF
select speed [1, 2 or 4]: 4
new packet size in quadlets: 1024
new frame size in quadlets: 10240
speed: 400MBIT
Quadlets per Packet: 0400
Quadlets per Frame: 2800
Setup finished.
transmit test.
0000
transmit operation finished

```

Figure 12: Sample *isotst* session

Examples for setting up the streaming registers are given in [4].

Figure 13 shows a recording of the generated data on the bus, recorded with a bus analyzer from an earlier version of *isotst*. The data was generated with the same settings as the sample session from Figure 12, with the difference that counter data and repetitive transmit (key 'T') is used. Random data would have caused larger gaps between the bursts, since it is calculated anew for each iteration. Each of the displayed packet bursts was generated by one execution of the transmit loop. The gaps between the bursts are caused by the iteration count display at the beginning of the transmit loop:

```
/* transmit loop */
```

```

while(1)
{
  int iPackets; /* packet counter */
  /* display iteration count */
  DebugOutWordHex(uiTxTestCount);
  DebugOutConstString("\r");
  DebugFlush(); /* causes a gap in the data stream between each packet burst */
  uiTxTestCount++;
  ...
}

```

The small gaps between the packets show the amount of bus time that is kept free for asynchronous transactions

Please note: when running continuous receive operation, the incoming bandwidth must be limited by using a smaller packet size, e.g. 256 quadlets when a second C6713Compact-2 running *isotst* is used as data generator. Otherwise, FIFO overflow errors will occur.




Figure 13: Recorded *isotst* data

Modifications in *isotst.cdb* / *.tcf*

(*isotst.cdb* / *.tcf* is derived from *C6713CPT_225MHz_32MB.cdb* / *tcf*)

"Scheduling" → "HWI – Hardware Interrupt Service Routine Manager" → "HWI_INT6":

"function": LynxHALNodeISR

"Dispatcher" → "Use Dispatcher": (not selected)

"Scheduling" → "TSK - Task Manager": Insert a task with the following properties:

"General" → "comment": task containing the main loop


"Function" → "Task function": TASK_WorkingThread

task object renamed to: TSK_work

13 List of Abbreviations and Acronyms Used in This Document

API	<u>a</u> pplication <u>p</u> rogramming <u>i</u> nterface
ASCII	<u>a</u> merican <u>s</u> tandard <u>c</u> ode for <u>i</u> nformation <u>i</u> nterchange – a simple, widely used character coding standard
ATF	<u>a</u> synchronous <u>t</u> ransmit <u>E</u> IFO – a function block within the IEEE1394 chipset
BSP	<u>b</u> oard <u>s</u> upport <u>p</u> ackage: a combination of software and FPGA design that provides further functionality to the C6713Compact-2
CCS	<u>C</u> ode <u>C</u> omposer <u>S</u> tudio – TI's development environment
CE space	<u>c</u> hip <u>e</u> nable space – an address range of a TBD: TMS320Cxxxx DSP, associated with a specific CE signal
COM	COM port – name of the serial (RS-232) interface of a PC
configuration ROM	a dedicated area in the IEEE1394 address space for device identification
CPU	<u>c</u> entral <u>p</u> rocessing <u>u</u> nit = processor
CRC	<u>c</u> yclic <u>r</u> edundancy <u>c</u> heck – a checksum method with high error detection probability
CSL	<u>c</u> hip <u>s</u> upport <u>l</u> ibrary – a library with DSP-specific functions provided by TI
CSR	<u>c</u> ontrol and <u>s</u> tatus <u>r</u> egister
CTS	<u>c</u> lear <u>t</u> o <u>s</u> end – a handshake line of the RS-232 interface
DCAM	<u>d</u> igital <u>c</u> amera
DM port	<u>d</u> ata <u>m</u> over port – an interface of the IEEE1394 chipset for fast data transfers
DMA	<u>d</u> irect <u>m</u> emory <u>a</u> ccess – a fast data transfer method
DSP	<u>d</u> igital <u>s</u> ignal <u>p</u> rocessor
DSP/BIOS	a scalable real-time kernel for TI DSPs with preemptive multitasking
e.g.	<u>e</u> xempli <u>g</u> ratia (Latin) = for example
EDMA	<u>e</u> nhanced <u>D</u> MA – a specific kind of DMA used in C6000 DSPs
EMI	<u>e</u> lectromagnetic interference
EMIF	<u>e</u> xternal <u>m</u> emory <u>i</u> nterface – a peripheral of the TMS320C6713 DSP
FFS	<u>f</u> lash <u>f</u> ile <u>s</u> ystem – a proprietary file system which is integral part of some Orsys products
FIFO	<u>f</u> irst-in <u>f</u> irst-out – a specific kind of sequential memory
Flash	a specific kind of non-volatile memory
FPGA	<u>f</u> ield <u>p</u> rogrammable <u>g</u> ate <u>a</u> rray
GEL	<u>g</u> eneric <u>e</u> xtension <u>l</u> anguage – a file format for CCS initialization files
HPI	<u>h</u> ost <u>p</u> ort <u>i</u> nterface – a peripheral of the TMS320C6713 DSP
I/F	<u>i</u> nterface
I/O	input / output
i.e.	<u>i</u> d <u>e</u> st (Latin) = that is
IEEE	Association for advancement of technology, formerly named <u>I</u> nstitute of <u>E</u> lectrical and <u>E</u> lectronics <u>E</u> ngineers, Inc.
IEEE1394	specification of a high-speed serial bus
ISR	<u>i</u> nterrupt <u>s</u> ervice <u>r</u> outine – the part of the software that handles interrupts
IIDC	1394 Trade Association Instrumentation and Industrial Control Working Group, <u>D</u> igital <u>C</u> amera Sub Working Group, publisher of a standard for IEEE1394-based digital cameras
IIDC/DCAM	refers to devices that use the IIDC standard for IEEE1394-based digital cameras
isochronous	= at constant time intervals - a transfer method used in IEEE1394 communications
JTAG	<u>J</u> oint <u>T</u> est <u>A</u> ction <u>G</u> roup – name of an interface for testing and debugging hardware
KB	1024 byte

LED	<u>l</u> ight <u>e</u> mitting <u>d</u> iode
LLC	IEEE1394 <u>l</u> ink <u>l</u> ayer <u>c</u> ontroller
LSB	least significant bit
MB	1204 KB = 1048576 byte
Mbps	transfer speed in <u>b</u> its <u>p</u> er <u>s</u> econd; 1Mbps = 1000kbps = 10 ⁶ bps
MSB	<u>m</u> ost <u>s</u> ignificant <u>b</u> it
MCI	<u>m</u> icro <u>c</u> ontroller <u>i</u> nterface – an interface of the IEEE1394 chipset used for register access and basic operation
n/a	<u>n</u> ot <u>a</u> vailable / <u>n</u> ot <u>a</u> pplicable
N.A.	<u>n</u> ot <u>a</u> vailable / not applicable
N.C.	<u>n</u> ot <u>c</u> onnected
Phy	<u>p</u> hysical layer transceiver (e.g. for IEEE1394 or Ethernet)
PLD	<u>p</u> rogrammable <u>l</u> ogic <u>d</u> evice
quadlet	defines a 32-bit data word (a group of 4 bytes), frequently used in IEEE1394 terminology
RAM	<u>r</u> andom <u>a</u> ccess <u>m</u> emory
ROM	<u>r</u> ead- <u>o</u> nly <u>m</u> emory
RS-232	<u>r</u> ecommended <u>s</u> pecification <u>232</u> – A widespread standard for serial communication
SDRAM	<u>s</u> ynchronous <u>d</u> ynamic <u>r</u> andom <u>a</u> ccess <u>m</u> emory
TBC	<u>t</u> o <u>b</u> e <u>c</u> hanged = value not 100% tested and may change in future
TBD	<u>t</u> o <u>b</u> e <u>d</u> efined = value is not yet specified
TI	<u>T</u> exas <u>I</u> nstruments
UART	<u>u</u> niversal <u>a</u> ynchronous <u>r</u> eceiver <u>t</u> ransmitter

	<p style="text-align: center;">USER'S GUIDE MICRO-LINE BUSMASTER BSP FOR THE C6713COMPACT-2</p>	<p>Date : 25 June 2012 Doc. no. : C6713Cpt-2_ml_bm_ug Iss./Rev : 1.0a Page : 40</p>
---	--	--

14 Literature references

Further information that is not covered in this user's guide can be found in the documents listed below. References to this list are given in square brackets throughout this document. The documents are listed by title, author and literature number or file name

- [1] *C6713Compact-2 hardware reference guide*, Orsys, C6713Cpt-2_hrg
- [2] *Flash File System User's Guide*, Orsys, FFS_ug
- [3] *Board Library Documentation for the micro-line® C6713Compact-2*, Orsys, boardlib.pdf
- [4] *C6713Compact-2 DM Port Streaming Core*, Orsys, C6713Cpt-2_str_core_ug
- [5] *IEEE1394 embedded API User Guide*, Orsys, embedded_API_ug
- [6] *Texas Instruments website at www.ti.com*
- [7] *TMS320C6000 Technical Brief*, TI, SPRU197
- [8] *TMS320C6713 floating-point digital signal processor data sheet*, TI, SPRS186
- [9] *TMS320C6000 CPU and instruction set reference*, TI, SPRU189
- [10] *TMS320C6000 peripherals reference guide*, TI, SPRU190
- [11] *TMS320C6000 DSP Host Port Interface (HPI) Reference Guide*, TI, SPRU578
- [12] *TMS320C6000 DSP Multichannel Audio Serial Port (McASP) Reference Guide*, TI, SPRU041
- [13] *TMS320C6000 DSP Software-Programmable Phase-Locked Loop (PLL) Controller Reference Guide*, TI, SPRU233
- [14] *TMS320C6000 DSP Inter-Integrated Circuit (I2C) Module Reference Guide*, TI, SPRU175
- [15] *TMS320C6713 Errata Sheet*, TI, SPRZ191
- [16] *Manual Update Sheet for TMS320C6000 Peripherals Reference Guide (SPRU190)*, TI, SPRZ122
- [17] *application report "Applications Using the TMS320C6000 Enhanced DMA"*, TI, SPRA636
- [18] *application report "TMS320C621x/TMS320C671x EDMA Queue Management Guidelines"*, TI, SPRA720
- [19] *How to Begin Development Today With the TMS320C6713 Floating-Point DSP*, TI, SPRA809
- [20] *Optimizing C-Compiler user's guide*, TI, SPRU187
- [21] *TMS320C6000 Assembly Language Tools User's Guide*, TI, SPRU186
- [22] *TMS320C62x/C67x Programmer's Guide*, TI, SPRU198
- [23] *TSB12LV32 data manual*, TI, SLLS336
- [24] *IEEE Standard for a High Performance Serial Bus*, IEEE, 1394-1995
- [25] *IEEE Standard for a High Performance Serial Bus-Amendment 1*, IEEE, 1394a-2000



Kane Computing Ltd
1 Verdin Street
Northwich
Cheshire
CW9 7BX
Tel: +44(0)1606 351006
Email: sales@kanecomputing.com
Web: www.kanecomputing.co.uk